

CUSTOMER SHOP
WIRING WIRING

ED206-104-6D-N1 & N12

NOTE:
-USE DIODES IN941S FOR
THUMBWHEEL SWITCHES
WIRES SOLDERED DIRECTLY
TO PCB
-FOR THUMBWHEELS ASSEMBLY
SEE "GREEN BOOK"

