


## E2000 Simple Programming Guide

	Turn power ON or OFF
	Start text programming
	Finish text programming
	Move cursor left one character
	Move cursor right one character
	Move cursor left one word
	Move cursor right one word
	Change to next format
	Change to previous format
	Toggle between capital and lowercase
	Toggle between insert mode and overwrite mode
	Delete the character after cursor
	Delete the character before cursor
	Clear all text
	Input a space character
	Insert a new line
	Select font
	Select color
	Insert date and time
	Insert a counter
	Insert temperature

Steps to programming  
your EDV111-#####-MC  
display through a remote

With the display on,  
press the Program  
(PROG) Button

New Message

Edit Message

Press the Enter button  
(ENT) over  
PROG TEXT  
- NEW -

Use the right and left arrow buttons  
to find the message list name you want  
to edit, then press Enter (ENT).

Input the name you want  
your message list to be  
saved as and press Enter  
(ENT) button.

Enter your message  
you want displayed.

When you're done  
inputting the message  
press the Run (RUN)  
button.

Cycle through the **Move Methods** by pressing  
the '**MET**' button (Set before the words you  
want to have the method).

Cycle through **colors** by pressing the '**COL**'  
button (Select color before inputting word to set  
its color).

Change the **font/size** by pressing the '**FONT**'  
button.

Change from **capital** to lowercase letters and  
vice versa by pressing the '**CAP**' button.

Insert **spaces** between words by pressing  
the '**SPA**' button.

**Clear all** the text by pressing the '**CLR**'  
button.

Insert the **Time** by pressing the '**TIME**'  
button  
**\*\*Note\*\*** May need to adjust time  
(See other manual for instructions).

Message Properties