

ELECTRONIC DISPLAYS INC.

135 S. CHURCH STREET
ADDISON, ILL. 60101

www.electronicdisplays.com



EDV206-104-4D-STACK



The display will up or down time in MM:SS. When it reaches “00:00”, the stack light will turn on and a buzzer will activate.

Parts List:

- EDV206 display with power adapter Qty: 1
- IR remote / Mounting Brackets Qty :1

Infrared Remote (IR) Overview

Display Configuration

Preset Display

1. Press the **EDIT** button.
2. Change the value of the flashing digit using the number buttons on the remote.
3. Press the **ENTER** button to save the value on the display.

Up / Down Timing

1. Press the **UP** button to up-time in MM: SS.
2. Press the **DOWN** button to down-time in MM: SS.
3. Press **START** to time
4. Press **STOP** to pause the timing

Please visit our website for more information:

www.electronicdisplays.com

Or Call: 1-800-367-6056

Or Our Support Website:

<http://edisupport.helpserve.com/>