



## EDX06-102-4D-N1 Timing Change from MM:SS to HH:MM



- Unplug the Display from Power
- Slide out the PCB from the Extrusion
- Move Position "6" to the "ON" position
- Slide Back the Display

