

ELECTRONIC DISPLAYS INC.

135 S. CHURCH STREET
ADDISON, ILL. 60101

www.electronicdisplays.com



Setting time and color for -101- clock

The clock time and color are set by using two push buttons located on the right side of the display.

RIGHT push button will allow you to set the mode.

LEFT push button will allow you to set the time value or color.

1. Push the RIGHT push button 4 times. This will allow you to set the hour value.
2. Push the LEFT push button to the desired hour value. This will show on the right most digits.
3. Push the RIGHT push button 1 time. This will allow you to set the minute value. This will show on the right most digits.
4. Push the LEFT push button to the desired minute value. This will show on the right most digits.
5. Push the RIGHT push button 2 times. This will allow you to select the color of the display.
6. Push the LEFT push button for the desired color.
7. Push the RIGHT push button 1 time to put the display in clock mode.