

ELECTRONIC DISPLAYS INC.

135 S. CHURCH STREET
ADDISON, ILL. 60101

www.electronicdisplays.com



EDV800D-I-104-9D-N1-IR

Parts List:

- 8" High Downtimer in DDD:HH:MM:SS with Power Cable
 - IR Remote with Battery

EDV Downtimer in DDD:HH:MM:SS Time Format Quick Setup

The EDV display will down-time in DDD:HH:MM:SS format. An IR remote (supplied) programs the display and controls the run/hold. Two mounting eyehooks allow the user to hang the display or attach to a wall.

To configure the display using the IR remote follow these instructions:

"A" Key = Set / Confirm

"B" Key = Next

"C" Key = Add (in TIME mode)/ Minus (in DAYS mode)

"D" Key = Minus (in TIME mode) / Add (in DAYS mode)

To Preset the **TIME in HH:MM**

1. Enter the hours and minutes mode
 - a. Preset Hours: Press **"A"**. The 2 digit **HOURS** LED field will blink. To add hours, press **"D"**. To subtract hours, press **"C"**. Press **"A"** again to save hours.
 - b. Preset Minutes: Press **"B"**. The 2 digit **MINUTES** LED field will blink. To add hours, press **"D"**. To subtract hours, press **"C"**. Press **"A"** again to save hours.

To Preset the **DAYS in DDD**

2. Enter the days mode
 - a. Press **"B"**. The days LED field will clear to "0". To add days, press **"C"**. To subtract days, press **"D"**.

Notes

If nothing is entered, the display will automatically start from the last preset value after 10 seconds.

Please visit our website for more information:

www.electronicdisplays.com

Or Call: 1-800-367-6056

Or Our Support Website:

<http://edisupport.helpserve.com/>