

# ***ELECTRONIC DISPLAYS INC.***

135 S. CHURCH STREET  
ADDISON, ILL. 60101

[www.electronicdisplays.com](http://www.electronicdisplays.com)



## **EDV206-104-10D-IR**



### Parts List:

- EDV206-104-10D-IR
- Infrared Remote

Qty: 1

Qty: 1

# Infrared Remote (IR)



**Turn Display On/Off**



**Edit the values on the display**




**Turn alarm on/off**



**Saves display value after EDIT button pressed**



**Set Display to Time Up**



**Set Display to Time Down**



**Stop Timing**

**Move to left digit**



**Move to right digit**

# Display Configuration

## To set the value on the display:

1. Point the Infrared Remote (IR) towards the front right of the display and press the **EDIT** button on the remote.
2. Input the desired numeric value to replace the blinking digit on the display.
3. Press **ENTER** button on the remote to save the values entered.

## To turn ON a alarm for when the display reaches zero:

1. Point the Infrared Remote (IR) towards the front right of the display and press the **SETUP** button on the remote until **ON** is briefly displayed in the DAYS section of the display.

## To turn OFF a alarm for when the display reaches zero:

1. Point the Infrared Remote (IR) towards the front right of the display and press the **SETUP** button on the remote until **OFF** is briefly displayed in the DAYS section of the display.

## Start Timing:

- To begin Timing **UP**, press the **Up arrow** in the TIMER section of the remote
- To begin Timing **DOWN**, press the **Down arrow** in the TIMER section of the remote

## Stop Timing:

- To stop timing, press the **STOP** button

## Display Notes:

- Display only times up or down when the display is turned **ON**.
- The battery for the infrared remote is a **CR2025**

---

Please visit our website for more information:

[www.electronicdisplays.com](http://www.electronicdisplays.com)

Or Call: 1-800-367-6056

Or Our Support Website:

<http://edisupport.helpserve.com/>