

RTA EDS FILE

If you need an EDS file, you need to call RTA to get the EDS file this gateway. When you install the EDS file using the EDS wizard, then RS Linx will show them the gateway, HOWEVER that does not make it communicate and work in the PLC.

You need to follow the procedure in the manual to create a GENERIC ETHERNET IP device.

This is also noted in the video series here:

<https://www.youtube.com/watch?v=Y0sTTH6Xzws&list=UUQaXZutjiz1D0EadcxsIW1A>

The video explains how to connect the Gateway to the PLC.

In other words, installing the EDS is not going to gain you anything other than allow RS Linx to ID the Gateway properly, which when you configure the PLC, the PLC doesn't use RS Linx anyways...