

ELECTRONIC DISPLAYS INC.

135 S. CHURCH STREET


ADDISON, ILL. 60101


www.electronicdisplays.com



Removing the Audio Function on the EDV111 Industrial Message Displays

1. Make sure that your software is configured as **dealer**.
2. From the CD open the software/ bin file. Locate the “**Config note pad**” file and open it.
3. Change the **Settings** , ProductTarget= dealer
4. **Save**
5. Open WZP software
6. Click on “**Comm**” menu
7. Click on the “**sign config**’ tab . Make sure that the width and height are correct (if not enter your signs Width and heights, now)





8. Click on the **“Others”** tab
9. Check the box beside **“Disable System Beep”**
10. Click **“OK”**

